



# Installation Procedures





## Install Guide

These instructions are important, so please read & follow them to ensure your client does not lose their warranty. Please call if you have any questions.

## Presite Check

- Firstly, inspect bench top upon arrival. Advise The Woodsmiths immediately of any damage.
- If Resin finish, the benchtop may appear cloudy or uneven, this is just due to the packaging absorbing the wax. We suggest applying a fresh coat of wax - supplied in kit addressed to customer - and wiping off excess with a rag. Please note this finish may not have fully cured yet. Which means it is still hardening.
- Do not put anything heavy, hot or sharp on top as this could mark the coating.
- Check that bench top will have sufficient support all-round.
- All breakfast bars and overhangs over 300mm with no steel supports need support from wall brackets or legs. Unless specified previously by The Woodsmiths.
- Site Joins - Mask each top right on join line. Apply bead of Clear Silicone to one top. Pull joint together with toggle bolts (supplied). Clean up silicone with turps or soapy water.
- Screw down bench top at no closer than 600mm centres with screws and washers supplied. Drill 15mm clearance holes through cabinetry rails and predrill top with 2mm drill.
- Screw no closer than 60mm from end of top.

## Alterations to bench top

Any trimming of the benchtop (i.e. scribing to wall, faucet holes) **must** be sealed with two coats of two-pack polyurethane. Faucet flange must be silicone sealed to bench top. All major cut-outs, (hobs, bowls and tiles) to be done in our factory.

## Underneath heat and moisture

Bench tops must be insulated from any heat and moisture from hot water cylinders and dishwashers. Polystyrene packaging could be fixed to under side of top for this.